Call 1-800-4MY-HOME® (1-800-469-4663) for Service Parts

GIVE THE FOLLOWING INFORMATION:
MODEL NUMBER MODEL DESCRIPTION
PART NUMBER PART DESCRIPTION
QUANTITY PART COLOR

#	PART NO.	DESCRIPTION
1	1003249-ERED	BACKSPLASH – RED
2	1003477-ERED	STIFFENER - RED
3	M15865	NAMEPLATE
4	1003046-ERED	RAIL – RED
5	1000232-ERED	SIDE – RED
6	27563A2-PN	LEVELING FOOT
--	F1725	INSTRUCTION SHEET
--	1003536	HARDWARE BAG

CRAFTSMAN®

SERVICE PARTS

Model No. **706.149250**
WORKBENCH

Modelo No. **706.149250**
BANCO DE TRABAJO



Llame al 1-800-659-7084 para Piezas de Servicio

INDICAR LA SIGUIENTE INFORMACION:
NUMERO DE MODELO DESCRIPCION DEL MODELO
NUMERO DE PIEZA DESCRIPCION DE LA PIEZA
CANTIDAD COLOR DE LA PIEZA

#	No. DE PIEZA	DESCRIPCION
1	1003249-ERED	PROTECTOR CONTRA SALPICADURAS -ROJO
2	1003477-ERED	REFUERZO - ROJO
3	M15865	PLACA DE NOMBRE
4	1003046-ERED	RAIL – ROJO
5	1000232-ERED	LATERAL – ROJO
6	27563A2-PN	PATA NIVELADORA
--	F1725	HOJE DE INSTRUCCIONES
--	1003536	BOLSA DE QUINCALLERIA

NOTE:
1. ALL UNNUMBERED PARTS ARE INTERCHANGEABLE WITH THE OPPOSITE SIDE.
2. REPLACEMENT KEYS MAY BE ORDERED USING THE CODE WHICH APPEARS ON THE FACE OF THE LOCK.

NOTA:
1. TODAS LAS PIEZAS SIN NUMERO SE PUEDEN INTERCAMBIAR CON LAS DEL LADOS OPUESTO.
2. SE PUEDEN PEDIR LLAVES DE RECAMBIO USANDO LA COMBINACION DE LETRAS Y NUMEROSO QUE APARECE COMO EL NUMERO DE PIEZA EN LA CARA DE LA CERRADURA.